BP601G1 Tech Sheet

Customer:	Balboa Water Group
Part Number:	56497-01 800 Incoloy 56498-01 825 Incoloy 56499-01 Titanium
Custom Box Overlay	
Box Overlay Part Number	N/A
CE System Model: Software Version ID:	BP6-BP601G1-RCA-3.0KW M100_206 V15.0
Software Version:	15.0
File Name:	BP601_15.0_BP601G1_2.hex
Configuration Signature:	63D9CF45
Eng. Project Number:	4127
Base PCBA:	56500-01
Control Panels (See later)	pages for more information):
TP800	Version 3.1 and later
TP600CE	Version 2.7 and later - TP600 (non-CE) should not be used
TP400T	Version 2.7 and later

Version 2.7 and later

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



TP400W

System Revision History

EPN	Date	Originator	Changes Made
3899	05-13-13	BWG	BP601G1 initial draft
N/A	06-12-13	BWG	Corrections to Tech Sheet
4127	08-28-13	BWG	Issue found with Serialized Purge on one-pump-only Setups.
	3899 N/A	3899 05-13-13 N/A 06-12-13	3899 05-13-13 BWG N/A 06-12-13 BWG



Basic Functions Setup 1 - 6

Power Requirements:

Single Service [3 wires (line, neutral, ground)]
230VAC, 50Hz, 1b, 16A, (Circuit Breaker rating = 20A max.)
Single Service [3 wires (line, neutral, ground)]
230VAC, 50Hz, 1b, 32A, (Circuit Breaker rating = 40A max.)


System Ouputs:

Pump 1	230VAC	in Setups 1, Must deliver	3, 5, this is 20 GPM thro	on service available (16A vs. 32A), other equipment installed, and if A5 is set to ON for Special Amperage Rule B. the heater pump.
		1 Speed in S	Setups in Setu	ıps 2, 4, 6
Pump 2	230VAC		•	nax 15-minute timer on service available (16A vs. 32A), other equipment installed, and if A5 is set to ON for Special Amperage Rule B.
Blower	230VAC	1-Speed Used in Setu	4A max 1p 3 & 4	15-minute timer
Circ Pump	230VAC		2A max leater pump i 20 GPM thro	Programmable Filtration Cycles + Polling n Setups 2, 4, 6. ugh heater
Ozone	230VAC		.5A max	Slaved to Circ Pump in Circ Setups and to Pump 1 Low in Non-Circ Setups
Spa Light	10VAC	0n/0ff	1A max	240-minute timer.
A/V (Stereo)	230VAC	Hot	4A max	Always on
Heater	3.0kW @ 24	40VAC max		



Hardware Setup

Wiring Diagram





Setup Reference Table

Setup #	Circ Pump	Pump 1	Pump 2	Pump 3	Blower	Temp Scale
1	None	2-Speed	1-Speed	None	None	°C
2	Programmable Filtration + Polling	1-Speed	1-Speed	None	None	°C
3	None	2-Speed	None	None	1-Speed	°C
4	Programmable Filtration + Polling	1-Speed	None	None	1-Speed	°C
5	None	2-Speed	None	None	None	°C
6	Programmable Filtration + Polling	1-Speed	None	None	None	°C

System is shipped in Setup 1



Changing Software Setups with TP800


Test Menu Access (S1, Switch 1 ON) Service Technician ONLY.

DANGER! HIGH VOLTAGE WILL BE ACCESSIBLE! SERVICE TECHNICIAN ONLY!

While the system is running, move DIP Switch 1 (on S1 on the Main circuit board) to ON. The system will enter Test Mode. Moving DIP Switch 1 to OFF will exit Test Mode.

Software Setups

Under the TEST Menu, the Setup screen will allow changing the Setup from 1 to any number established by the Manufacturer. Changing the Setup may require wiring changes as well.



6

S1



Changing Software Setups with TP600/400

Test Menu Access (S1, Switch 1 ON) Service Technician ONLY.

DANGER! HIGH VOLTAGE WILL BE ACCESSIBLE! SERVICE TECHNICIAN ONLY!

While the system is running, move DIP Switch 1 (on S1 on the Main circuit board) to ON. The system will enter Test Mode. Moving DIP Switch 1 to OFF will exit Test Mode.

Software Setups

Under the TEST Menu, the Setup screen will allow changing the Setup from 1 to any number established by the Manufacturer. Changing the Setup may require wiring changes as well.

You will have 1 minute to complete the setup change after you manually exit Priming Mode. (Once familiar with the process, the Setup change should take less than 15 seconds.)



When the panel displays RUN PMPS PURG AIR, press any Temperature button ONCE to exit Priming Mode. You should see "---T" where the T indicates the system is in Test Mode.



Continued on Next Page.

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending. © Copyright 2009 Balboa Water Group.



As soon as Switch #1 is placed in the ON position, the temperature will show "T" after it instead of F or C, indicating the System is in Test Mode

Changing Software Setups with TP600/400 Continued


Again, You will have 1 minute to complete the setup change after you manually exit Priming Mode.

Immediately after exiting Priming Mode, press this sequence of buttons: Warm*, Light, Warm, Warm, Warm. Continue to press Warm until the diplay shows the Setup Number (S-01, S-02, etc.) you want to switch to. When the correct setup number is showing, press Light once, and the system will reset, using the newly-selected Setup from that point on.

Move DIP Switch 1 to the OFF position to take the spa out of Test Mode. °F or °C will replace °T.

Using a permanent marker, write the Setup number on the Setup label mounted inside the system lid (right). This is very important to any service person in the future who may need to replace a circuit board or system and needs to change the Setup on a replacement part while in the field.

NOTE: Changing the Setup may require wiring changes as well - refer to the wiring diagram or wiring diagram addendum.



Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending. © Copyright 2009 Balboa Water Group.



THIS SYSTEM IS

CONFIGURED AS SETUP #

Equipment Expansion

Expansion Features

Control Connection

Relay 1/2 (J108)

None

Default

Fuse



DIP Switch Functions

Fixed-fuction DIP Switches

- A1 Test Mode (normally Off).
- A2 In "ON" position, add one high-speed pump (or blower) with Heater.
- A3 In "ON" position, add two high-speed pumps (or 1 HS Pump and Blower) with Heater.
- A5 In "ON" position, enables Special Amperage Rule B. See Special Features section under Configuration Options for functionality with your system. In "OFF" position, enables Special Amperage Rule A.
- A6 Persistent memory reset (Used when the spa is powering up to restore factory settings as determined by software configuration).

A2 and A3 work in combination to determine the number of high-speed devices and blowers that can run before the heat is disabled. i.e. A2 and A3 in the ON position will allow the heater to operate with up to 3 high-speed pumps (or two HS Pumps and Blower) running at the same time. Heat is disabled when the fourth high-speed pump or blower is turned on.

Note: A2/A3 all off = No heat with any high-speed pump or blower.

Assignable DIP Switches

A4 In "ON" position, enables a 5-minute cooldown for some gas heaters (Cooling Time B). In "OFF" position, enables a 1-minute cooldown for electric heaters (Cooling Time A).

Undesignated switches are not assigned a function.



Jumper Definitions

J109	Non Applicable on CE models	J109	
J30	Do Not Use		
31	Jumper on 1 pin with 2.0kW or smaller heater Jumper on 2 pins with a 3.0kW or higher heater	J31	
J29	Heater Disable Switch Connection. If J29 is shorted by any means, the heater will not run until J29 is no longer shorted. If J29 is shorted during power-up "J29" will appear on the panel. The message can be dismissed with a button press, and is the only control panel notification of J29 being shorted. No message is displayed if J29 is shorted after power-up, but the heater will not run until J29 is no longer shorted. J29 expects a switch closure (not a voltage) as the command signal. In some areas, a local power company may offer discounts based on voluntary "power shedding" devices that may be install	J29 led in conju	onction with the spa.
J25, J26, J27	Heater Type Settings. <i>Note: Factory Configured do not change.</i>	J25	۲ J27 ایک ایک
J44	Jumper must be on center two pins (230V) for CE Systems.	J44 (230V 2 0 0 0 115 15V
Warning!			
	etting DIP switches or jumpers incorrectly may cause abnormal system behavior and/or damage to system components. Ifer to Switchbank illustration on Wiring Configuration page for correct settings for this system.		

Contact Balboa if you require additional configuration pages added to this tech sheet.



General Features		
Feature	Default	
Pump 1 in Filter Cycle (Circ Only)	No	
Pump 1 Low Timer	30 Minutes	Applies in non-circ Setups (configurations) only
General Pump Timer	15 Minutes	
Blower Timer	15 Minutes	
Mister Timer	15 Minutes	
Light Timer	240 Minutes	
Circ (when enabled)	Programmable + Polling	
Cleanup Cycle	30 Minutes	
Cleaup as Preference setting	Yes	
Ozone	With Heater Pump*	
Ozone Suppression	OFF	
Pump Purge	60 Seconds	
Blower Purge	30 Seconds	
Mister Purge	5 Seconds	
Purge Type	Serial - Pumps at lowes	t speed
	except Simultaneous Pu	rge for Setup 5

* The heater Pump can be either a Circ Pump or Pump 1 Low.

Blue Indicates New Custom Configuration Default (Setup 1)



Temperature Features		
Feature	Default	
Temperature Display	°C	°C, °F

All temperatures must be specified in °F. The system converts °F to °C dynamically. If Celsius is required for default settings, choose a desired °C value that (after rounding) corresponds to a Fahrenheit value.

°C	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	<i>19</i>	20	21	22
°F	39	41	43	45	46	48	50	52	54	55	57	59	61	63	64	66	68	70	72
°C	23	24	25	26	27	28	<i>29</i>	30	31	32	33	34	35	36	37	<u>38</u>	<u>39</u>	40	
°F	73	75	77	79	81	82	84	86	88	90	91								
Hi-F	ange l	Min.S	et Ter	np				80°F											
Hi-F	ange l	Max. S	et Te	mp				104°	F										
Hi-F	ange l	Defaul	t Tem	p*				100°	F										
Lo-F	lange	Min.S	et Tei	mp				50°F											
Lo-F	lange	Max. S	Set Te	mp				99°F											
Lo-F	ange	Defau	t Tem	ıp*				70°F											
Free	ze Thr	esholo	ł					44°F											
Free	ze Typ	e						Rotat	ting -	Pump	s at L	owest	Spee	d					
Tem	p Lock	Туре						Temp) + Set	tings									

*May be changed by end-user (if enabled)

Blue Indicates New Custom Configuration Default (Setup 1)



Time Features	
Feature	Default
Time Format*	12 Hour
Filter 1 Start Hour*	20:00 (8:00 PM)
Filter 1 Duration*	2 Hours
Filter Cycle 2 Default*	OFF
Filter 2 Start Hour*	08:00 (8:00 AM)
Filter 2 Duration*	15 Minutes
Light Cycle	Disabled
Light Cycle Default*	OFF
Light Cycle Start Hour*	21:00 (9:00 PM)
Light Cycle Duration*	15 Minutes
	-or or Disabled
Cooling Time A	1 Minute

*May be changed by end-user (if enabled)

Blue Indicates New Custom Configuration Default (Setup 1)



Cooling Time B Reminder Features	5 Minutes			
Feature	Default			
Reminders Shown*	Yes			
Check pH	OFF			
Check Sanitizer	OFF			
Clean Filter	30 Days			
Test GFCI	65 Days			
Drain Water	100 Days			
Change Cartridge	OFF			
Clean Cover	OFF			
Treat Wood	OFF			
Change Eilter	DAE Dave			

*May be changed by end-user (if enabled)

Blue Indicates New Custom Configuration Default (Setup 1)



Default

No Limitation

Special Amperage Rule B	1 HS Pump - Blower turns off with 1 HS Pump
Drain Mode	Disabled
Demo Mode	Disabled
Automatic GFCI Test	Disabled
Ozone Slaved to Heater Pump	<i>Yes</i>
Dual Voltage Heater	Always Input Voltage
Safety Suction	Disabled

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending. © Copyright 2009 Balboa Water Group.



Special Features

Special Amperage Rule A

Feature

TP800 Panel Configuration

Button Layout Table

Feature #	Setup 1	Setup 2	Setup 3	Setup 4	Setup 5	Setup 6
A1	N/A	N/A	N/A	N/A	N/A	N/A
A2	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
A3	Jets 2	Jets 2	Blower	Blower	Light 1	Light 1
A4	Light 1	Light 1	Light 1	Light 1	Invert	Invert
A5	Invert	Invert	Invert	Invert	Undefined	(Circ Icon)
A6	Undefined	(Circ Icon)	Undefined	(Circ Icon)	Undefined	Undefined
A7	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A8	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A9	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A10	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A11	N/A	N/A	N/A	N/A	N/A	N/A
A12	N/A	N/A	N/A	N/A	N/A	N/A
A13	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A14	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A15	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
A16	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
B1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1	Jets 1
B2	Undefined	Undefined	Undefined	Undefined	Undefined	Undefined
B3	Jets 2	Jets 2	Blower	Blower	Undefined	Undefined
B4	Light 1	Light 1	Light 1	Light 1	Light 1	Light 1


Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



Template 56377 10-05-12


TP800 Panel Configuration

Spa Screen



Note: Button B2 is ALWAYS unused on TP800 when used with this sytsem. A custom overlay will be required.

Shortcuts Screen



Note: Buttons 11 and 12 are not used in this configuration.

Button 1 is fixed.

Panel Part Number	50204-05
Overlay Part Number	N/A



TP600 Panel Configuration

Button Layout Table

Button #	Setup 1 & 2	Setup 3 & 4	Setup 5 & 6
1	Jets 1	Jets 1	Jets 1
2	Jets 2	Blower	Undefined
3	Invert	Invert	Invert
4	Up	Up	Up
5	Light 1	Light 1	Light 1
6	Down	Down	Down
LED 1	Jets 1	Jets 1	Jets 1
LED 2	Jets 2	Blower	Undefined
LED 3	Light 1	Light 1	Light 1
LED 4	Heat On	Heat On	Heat On



TP600CE


50015-04 or later No Overlay TP600 (non-CE) should not be used.



TP400 Panel Configuration

Button	Layout	Table	for	TP400T
--------	--------	-------	-----	--------

Button #	Setup 1 & 2	Setup 3 & 4	Setup 5 & 6
1	Temperature	Temperature	Temperature
2	Jets 1	Jets 1	Jets 1
3	Light 1	Light 1	Light 1
4	Jets 2	Blower	Undefined
LED 1	Heater ON	Heater ON	Heater ON
LED 2	Jets 1 ON	Jets 1 ON	Jets 1 ON
LED 3	Light ON	Light ON	Light ON
LED 4	Jets 2 ON	Blower ON	Undefined



TP400T

50260-02 or later Includes overlay PN 12511.

Button Layout Table for TP400W

Button All Setups #	
π	
1 Up	
2 Down	
3 Light 1	
4 Jets 1	
LED 1 Heater ON	
LED 2 Undefined	•
LED 3 Light ON	
LED 4 Jets 1 ON]

Use the TP400W for setups that only have one pump (No Blower or Pump 2).

TP400W

50259-01 or later Includes overlay PN 12510.



Auxilliary Panel Features on Bank 1*

Feature	Default
Aux Button A1	Jets 1
Aux Button A2	Jets 2 in Setups 1 & 2 Blower in Setups 3 & 4 Undefined in Setups 5 & 6
Aux Button A3	Undefined
Aux Button A4	Light

*Bank 1 consists of J5 on the Main Circuit Board. Aux Connection Splitter PN25257 may be required.

Buttons that are assigned to equipment that is not defined in a Setup will not do anything in that Setup.

Manufactured under one or more of these patents. U.S. Patents: 5332944, 5361215, 5550753, 5559720, 5,883,459, 6253227, 6282370, 6590188, 6976052, 6965815, 7030343, 7,417,834 b2, Canadian Patent: 2342614, Australian patent: 2373248 other patents both foreign and domestic applied for and pending.



Template 56377 10-05-12

21

Auxilliary Panel Features


AX10 Panels on Bank 1*

 A1, AX10A1
 No 0/L
 52803

 A2, AX10A2
 No 0/L
 52804

 A3, AX10A3
 No 0/L
 55805

 A4, AX10A4
 No 0/L
 52806



Call Customer Service for additional information about Auxiliary Panels.

Auxiliary Panel Part Number ______ Overlay Part Number _____

*Bank 1 consists of J5 on the Main Circuit Board. Aux Connection Splitter PN25257 may be required.


AX20

 AX20 A1A2
 No 0/L
 52800

 AX20 A1A3
 No 0/L
 52801

 AX20 A1A4
 No 0/L
 52802


52799



AX20 Auxiliary Panel plugged into Bank 1 will operate A1 + A2, A3 or A4.

AX40

AX40 No 0/L



AX40 Auxiliary Panel plugged into Bank 1 will operate A1 + A2, A3 and A4.

